



DYE Precision Inc.

USA 10637 Scripps Summit Ct. San Diego, CA 92131 **P** 858-536-5183 **F** 858-536-5191

EUROPE Unit 1, ZK Park, 23 Commerce Way, Croydon, Surrey CRO 4ZS United Kingdom

P +44 (0) 20-8649-6330 **F** +44 (0) 20-8649-6339

ASIA 3F-2, No. 287, Jung Jeng Rd., Luju Hsiang, Taoyuan 338, Taiwan (R.O.C.)

P +886-3-312-6540 **F** +886-3-311-8723

www.dyepaintball.com

©2005 DYE Precision, Inc. The stylized "dye" logo, the "Sphere" logo, the "DM6" logo, FUSE bolt and Hyper² are either registered trademarks, trademarks, design trademarks, patents or pending patents of DYE Precision, Inc.

Covered by U.S. Patent # 5,613,483. Additional patents pending.



DM6

DM6 OWNER'S MANUAL

TABLE OF CONTENTS



INCLUDED WITH YOUR DM6

- DM6 Marker
- Allen tool set including 1/16", 5/64", 3/32", 1/8", 5/32", 3/16" and 1/4"
- 1 oz. Dye Slick Lube™
- Parts Kit
- Barrel Sock
- Owner's Manual
- Warranty Card

ADDITIONAL RECOMMENDED TOOLS

- 3/8" Allen wrench
- 5/16" Allen wrench
- Canned Air

<< SPECS >>

WEIGHT	[1.7 LBS]
WIDTH	[1.25"]
LENGTH	[9"]
HEIGHT	[8"]
EFFICIENCY	[1,300 SHOTS OFF 68CU 4500PSI]
BATTERY LIFE	[40,000 SHOTS]
OPERATING PRESSURE	[145PSI]
CYCLE PRESSURE	[70PSI]
MAX RATE OF FIRE	[30+BPS, LIMITED TO HOPPER FEED RATE]
BARREL THREAD	[COCKER]

QUICK REFERENCE	PAGE 02
IMPORTANT SAFETY INSTRUCTIONS AND GUIDELINES	PAGE 03
BOARD SETTINGS AND FUNCTIONS	PAGE 04
FUSE BOLT	PAGE 08
LOW PRESSURE REGULATOR (LPR)	PAGE 10
ON/OFF VALVE	PAGE 11
HYPER2™	PAGE 12
ANTI CHOP EYES/ BALL DETENTS	PAGE 13
ULTRALITE FRAME	PAGE 14
EXPLODED VIEW	PAGE 15
TROUBLE SHOOTING GUIDE	PAGE 16
WARRANTY INFORMATION	PAGE 17

QUICK REFERENCE - USING YOUR MARKER

Air Supply - The DM6 should be operated using air/nitrogen gas only. This air needs to be supplied to the Hyper²™ in-line regulator at a regulated pressure of no more than 850 psi. The Hyper²™ in-line regulator comes factory preset at 145psi.

Turning On Your DM6 - The DM6's power is controlled with two buttons on the back side of the grip frame. The top button turns the marker on and off, while the bottom button turns the eye on and off. To turn the DM6 ON, press and hold the power button until the LED lights turn blue. The LED's in the grip will illuminate during the boot sequence.

NOTE: If the eye is not working properly, try replacing the battery.

Blue	-	Boot Sequence
Red	-	Breech is clear, no ball (eye on)
Green	-	Ball in breech, ready to fire (eye on)
Blinking Red	-	Eye is off
Blinking Green	-	Eye failure (see DM6 Board, page 5)
Blinking Blue	-	Indicates a low battery, battery should be changed as soon as possible

On/Off - The On/Off knob is located under the barrel at the front of the DM6. To turn the gas on, turn the knob counter-clockwise. To turn the gas off, turn the knob clockwise. All gas will vent from the DM6 when the knob is turned off. Air may still be present in the LPR and solenoid after the air has been vented from the marker by the on/off. Be sure all air has been vented by discharging the marker in a safe direction. If servicing the marker, removal of the bolt will also allow any trapped air to escape.

LPR - The LPR is pre-set from the factory at approximately 75-80 psi and should need no adjustment out of the box. If fine tuning adjustment is desired or needed, you must be sure that you are adjusting the LPR correctly. See

page 10 for detailed instructions. If the LPR is improperly adjusted, you could dramatically hinder the DM6's performance or prevent the marker from functioning at all.

NOTE: Turning the adjustment screw clockwise, or in, will lower the LPR's output pressure. Turning the adjustment screw counterclockwise, or out, will raise the LPR's output pressure.

Hopper - To get the best performance out of your DM6, it is recommended that you use a motorized loader. Preferably one that force feeds the paint really, really fast!

Feed Neck - To secure your loader into the adjustable feed neck simply tighten the thumbscrew by turning it clockwise. To loosen, turn the thumbscrew counter clockwise. Be careful not to over-tighten the collar as it can cause the neck to break.

Adjusting Velocity - The velocity is adjusted through the Hyper²™ in-line regulator. The Hyper²™ in-line is preset from the factory at approximately 145 psi. This pressure setting should have the marker shooting at about 285fps. Your paint-to-barrel fit will also have a noticeable affect on your velocity. Make sure that the paintball fits into the barrel loosely but does not drop through.

NOTE: For the Hyper²™, turning the adjustment screw clockwise, or in, will lower the output pressure, decreasing the velocity. Turning the adjustment screw counterclockwise, or out, will raise the output pressure, increasing the velocity.

NOTE: If the battery is too low, it may not be able to power the solenoid correctly. This will affect your DM6's velocity, causing it to become inconsistent and/or low.

⚠ WARNING

IMPORTANT SAFETY INSTRUCTIONS AND GUIDELINES

- The DM6 marker is not a toy. Misuse may cause serious injury or death.
- Please read, understand and follow the directions in the DM6 owner's manual.
- Eye protection that is designed specifically for paintball and meets ASTM/CE standards must be worn by user and persons within range.
- Recommend 18 years or older to purchase. Must have adult supervision if under 18.
- Always treat the DM6 marker as if it were loaded and able to fire.
- Only use compressed air or nitrogen gas in the DM6 marker. DO NOT USE CO₂.
- Do not exceed 850 psi input pressure.
- Ensure all air lines and fittings are tightened and secured before gassing up the DM6.
- Always chronograph the DM6 marker before playing paintball.
- Never shoot the DM6 marker at velocities in excess of 300 feet per second, or at velocities greater than local or national laws allow.
- Never look into the barrel or breech area of the DM6 when the marker is switched on and able to fire.
- Always fit a barrel blocking device to your DM6 when not in use on the field of play.
- The owner's manual should always accompany the product for reference or in the event of resale and new ownership.
- Do not point the DM6 marker at anything that you do not intend to shoot.
- Do not shoot at people, animals, houses, cars or anything not related to the sport of paintball.
- Do not fire the DM6 without the Fuse bolt screwed in completely.
- If you read these instructions and do not fully understand them or are unsure of your ability to make necessary adjustments properly, call DYE or your local pro shop for help.

DM6 BOARD - SETTINGS AND FUNCTIONS

FIGURE 1



WARNING

When servicing your marker:

- Make sure a barrel sock is fitted to the DM6.
- Make sure your hopper is removed from the DM6.
- Make sure there are no paintballs in the breech of the DM6.
- Always remove the first stage regulator and relieve all residual gas pressure from the DM6 before disassembly.
- The DM6 can hold a small residual charge of gas, typically 2 shots, with the first stage regulator removed. Always discharge the marker in a safe direction to relieve this residual gas pressure.

Turning the DM6 ON and OFF

To turn on the DM6, press and hold the power button (see figure 1) until the LED lights turn blue. The blue light indicates board bootup. After the bootup sequence, the LED's will turn either RED (no ball) or GREEN (ball ready to fire). To turn the DM6 off, press and hold the power button until the LED's turn off.

NOTE: The DM6 automatically switches off after 10 minutes of non-use.

Firing the DM6

As soon as the marker is turned on and the LED's turn from blue to either red or green, the DM6 is ready to fire. If there is no ball and the LED's are RED, you need to hold the trigger for 1 second to force the DM6 to fire once. If there is a paintball inside the breech and the LED is green, just press the trigger to fire the marker.

LED Light Indicator

The DM6 uses two super bright LED lights mounted on the circuit board inside the grip frame. These two lights are used to provide information to the user about the DM6. They will always show the same information and it does not matter which LED you look at. One is mounted behind the DM6 logo on the left side of the grip panels. The other one can be seen by looking at the top left side of the grip frame while holding the DM6 in the position you would while playing a game.

When you turn on the marker in normal operation mode with the power button, the light colors mean the following:

- | | |
|----------------|--|
| Blue | - Boot Sequence |
| Red | - Breech is clear, no ball (eye on) |
| Green | - Ball in breech, ready to fire (eye on) |
| Blinking Red | - Eye is off |
| Blinking Green | - Eye failure (see DM6 Board, page 5) |
| Blinking Blue | - Indicates a low battery, battery should be changed as soon as possible |

BLUE



RED



GREEN



NOTE: The eye is always activated when you turn the marker on.

DM6 BOARD - SETTINGS AND FUNCTIONS

Board settings and configuration mode

There are five settings you can alter on the DM6 board with the DIP switches inside the grip frame (see figure 2):

ABS	Anti Bolt Stick.
Trigger Sensitivity	This setting adjusts the delay between two trigger pulls.
Dwell	This is the time the solenoid is activated for.
ROF	Rate Of Fire when the eye is deactivated.
Firing Mode	This is the firing mode the DM6 uses

There are two DIP switches mounted on the board of the DM6 (See figure 2). The first one is used for the ABS setting and the second one is used to access a configuration mode used to change the other four settings.

Anti Bolt Stick -

When ABS is activated, the dwell is increased after 15 seconds of non-use for the next shot fired. This helps to prevent bolt-stick, but may result in higher velocity for the first shot.

FIGURE 2



WARNING

- The DM6 is not water resistant. Excess moisture can cause damage to electronic parts.
- Keep the board and all electrical components clean of dirt, paint and moisture.
- To clean the board, use canned air. If a more aggressive cleaning method is needed, lightly scrub the components with a soft, dry brush. Heavy scrubbing will damage the board.




ABS on (default)



ABS off

DM6 BOARD - SETTINGS AND FUNCTIONS

Configuration Mode - The following settings can only be modified in configuration mode. To activate the configuration mode, turn your marker off and set DIP switch 2 to the ON position. Next, turn your marker on. The LED's cycle through all colors for one second to indicate that you have entered the configuration mode. To cycle through different settings, pull and release the trigger. Configuration mode has 4 settings that can be changed.



Green - Trigger Sensitivity

Values 1 - 20 (factory default 5)
Trigger sensitivity is the amount of time that the trigger has to be released before the next trigger pull is allowed. In some situations with too low of a value, the DM6 can register more trigger pulls than what was actually pulled. This can cause the DM6 to shoot full auto, even in semi-automatic mode. To fix this, set trigger sensitivity setting higher.

Red - Dwell

Values 1 - 30 (factory default 18)
Dwell is the amount of time that the solenoid will be activated. Follow these steps for the best way to set your dwell:

- Remove loader and any paintballs from the DM6 marker.
- With the dwell set at 10, start increasing the value until the marker begins to fire.
- When you reach the setting where the marker begins to fire, get some paint and a loader and go to a chronograph.
- Increase the dwell until you see no increase in the velocity. This is the optimal dwell setting to be used.

Blue - Rate Of Fire (ROF) [When Anti Chop Eye (ACE) is deactivated]

Values 1 - 20 (factory default 20bps)
The ROF setting is used to set the maximum rate of fire of the DM6. The values do not correspond directly to a certain Balls Per Second (BPS) value. You will need to use the table below to locate your desired maximum ROF setting. The factory setting is 20 (30bps).

Value = BPS

1	10	11	15.6
2	11	12	15.9
3	12	13	16
4	13	14	18
5	14	15	20
6	14.5	16	22
7	14.7	17	24
8	14.9	18	26
9	15.2	19	28
10	15.4	20	30

Yellow - Firing Mode

Values 1 - 3 (default 1)
This setting changes the Firing mode of the DM6. Default is semiautomatic. In the semiautomatic mode, one trigger pull shoots out one paintball. The PSP/NPPL mode and The Millennium mode follow the rules of the paintball tournaments series.

Value 1 - NPPL/Semi automatic Mode
Value 2 - PSP Mode
Value 3 - Millennium Mode

NOTE: You cannot turn your marker off with the power button when the marker is in configuration mode. You must first set DIP switch 2 to the off position.

DM6 BOARD - SETTINGS AND FUNCTIONS

TO CHANGE THE VALUE OF A SETTING:

- 1 While in configuration mode, pull the trigger and hold it for more than one second. The LED will flash to indicate the previous setting. After that, you can set the new value with the trigger. For example, if you want to change the trigger sensitivity to 7 units:
- 2 Cycle through menus by pulling and releasing the trigger until the LED lights GREEN (trigger sensitivity).
- 3 Pull and hold the trigger until the LED starts to flash (factory default for trigger sensitivity setting is 5 units, so the LED will flash 5 times).
- 4 When the LED stops flashing, pull and release the trigger seven times in a fast pace. The new value is set after you haven't touched the trigger for one second. The LED will cycle through all colors to indicate that the new value is saved. All other configurations are changed the same way. Just as in part 2 above, change the mode to RED for "dwell" or BLUE for "ROF" to change the desired configurations.
- 5 To exit configuration mode, set DIP 2 to the off position.

Battery


Standard 9V batteries will last for about 40,000 shots. Please be aware that there are substantial differences in performance between different brands of batteries. Use of high quality alkaline or lithium ion batteries is recommended for maximum battery life. If you plan not to use your marker for a long period of time (a month), it is recommended that you remove the battery from the marker. An intermittent blinking blue light indicates a low battery. A low battery can cause malfunctions to the marker. In this case, the battery should be changed as soon as possible. When the battery voltage starts to go too low, you will notice your velocity starts to decrease and the board can turn off. For tournament use, it is recommended to change the battery for each tournament. When changing your battery, take special care to ensure the wiring harness is not pinched under the battery (see figure 1).

Changing the battery

The battery is housed on the right side of the grip frame. To access the battery, remove the three screws holding the right side grip panel down. Use a 3/32" Allen wrench. Carefully lift the battery out of the frame. When inserting a new battery notice the + and - marks on the board. The positive lead of the 9V battery goes to the left and the negative lead to the right. Inserting the battery backwards does not damage the board but it will not function.

NOTE: If the marker will not function with the eye on, there is a good chance the battery needs to be changed.

FIGURE 1



WARNING

- A low battery will not be able to power both the ACE eye and the trigger switch, causing ACE eye failure.
- If the battery is low, it may not be able to power the solenoid correctly. This will affect the DM6's velocity, causing it to become inconsistent and/or low.

FUSE™ BOLT - ASSEMBLY AND MAINTENANCE



FIGURE 1



FUSE™ BOLT OPERATION

To achieve top performance from your DM6, it is important to understand the basic operation of the DM6's patented FUSE™ bolt system.

This design consists of three sleeves threaded together to capture the only moving part of the system, the bolt.

The FUSE™ Bolt has four components

- 1 Cylinder
- 2 Bolt
- 3 Top Hat
- 4 Rear Cap

Air is supplied to the bolt at two points. A high-pressure supply of air is routed to the back of the bolt into the supply chamber. This air source is responsible for propelling the ball. Low-pressure air is supplied from the LPR to the solenoid. From the solenoid, the air is routed through two small holes to the section of the bolt referred to as the cylinder.

When the DM6 is aired up, air is transferred by the solenoid to the front of the cylinder. This air pushes against the bolt sail and the bolt is held in the back position. When the bolt is held back, the O14 o-ring in the top hat seals around the bolt and contains the air in the supply chamber.

When the marker is fired, the microswitch is pressed, telling the solenoid to switch the flow of air from the front of the cylinder to the rear of the cylinder. Air that enters the rear of the cylinder will push on the bolt sail, moving the bolt forward. The air in the front of the cylinder is vented.

As the bolt moves forward, the tapered stem passes through the top hat. Once the bolt stem can no longer seal against the O14 o-ring, the air contained in the supply chamber is released. The air passes through the venturi ports in the bolt and out the front of the bolt to propel the ball. When the bolt is in the forward position, the inside bolt stem o-ring prevents the flow of air from continuously flowing through the marker when the bolt is forward. This helps the marker shoot much more efficiently.

Note: Low or erratic velocity may be due to a low battery not supplying ample electrical current to the solenoid. In this case, change the battery.



FORWARD POSITION



BACK POSITION

WARNING

When servicing your marker:

- Make sure your hopper is removed from the DM6.
- Make sure there are no paintballs in the breech of the DM6.
- Always remove the air supply and relieve all gas pressure in the DM6 before disassembly.
- When using the DM6 in temperatures below 50° it may be necessary to lube the FUSE bolt more frequently.

FUSE™ BOLT - ASSEMBLY AND MAINTENANCE

BOLT MAINTENANCE

Regular DM6 Fuse™ bolt maintenance is vital to the performance of the DM6. If the Fuse™ bolt is not kept well-greased and the o-rings in good shape, the performance of the DM6 will be greatly hindered.

To remove the bolt, you will need a 1/4" Allen wrench. Unscrew the bolt from the rear of the marker. It only takes one and one half revolutions to unscrew the bolt so that it can be pulled out. After the bolt has been cleaned and greased and is ready to be inserted into the body, be sure all bolt sleeve components are screwed together snugly. Slowly push the bolt into the body. Take care not to cut or nick the o-rings as they pass the threads.

GREASE THE DM6 FUSE™ BOLT EVERY 10-15 THOUSAND SHOTS.

BEFORE INSTALLING THE BOLT INTO THE MARKER, BE SURE ALL BOLT SLEEVE COMPONENTS ARE SCREWED TOGETHER SNUGLY.

If you do not grease the bolt, you will run the risk of damaging o-rings. This will create excessive friction and drag on the bolt, ultimately resulting in breaking the bolt. When greasing the DM6 Fuse™ bolt, pay special attention to all o-rings that are on the bolt and that ride on a surface of the bolt. The first seven o-rings listed below should be generously greased during maintenance.

FUSE™ BOLT O-RING LIST

- | | |
|----------------------------------|---------------------------|
| 1 Bolt tip (O14 BN70) | 6 Top hat (O17 UR70) |
| 2 Bolt sail (O15 BN70) | 7 Top hat (O14 BN70) |
| 3 Inside bolt stem (O11 BN70) | 8 Outer sleeve (O20 BN70) |
| 4 Rear bolt stem (O11 BN70) | 9 Front bumper (O15 BN70) |
| 5 Front wall internal (O17 UR70) | 10 Rear bumper (I11 BN70) |

NOTE: ALL REMAINING O-RINGS SHOULD HAVE A THIN COATING OF GREASE AS WELL.






FIGURE 1



LPR ASSEMBLY, CLEANING, TESTING AND CHANGING SEALS

The Low-Pressure Regulator (LPR) is located in the lower back of the DM6 (see figure 1). The function of the LPR is to lower the air pressure supplied to the marker by the in-line, before it reaches the solenoid. This pressure is used to move the bolt forward and back. The factory setting is 75 PSI. You can fine tune your DM6 to its minimum cycle pressure. This will reduce the amount of force of the bolt hitting the ball (reducing ball breaks) and help with efficiency. Too low of pressure will cause the bolt to not cycle, move sluggishly or not at all. If you experience dramatic shoot down during rapid fire, the LPR may be adjusted too low. Too high of pressure will cause the marker not to shoot as smoothly, potentially increase ball breakage and cause undue wear and fatigue on the bolt components.

It is important to keep the seat and piston face clean of all dirt and debris. Clean the seat and piston face and grease the retainer o-ring every six months or 60,000 shots.

The LPR has five components and six seals

- | | |
|----------------------------------|---|
| 1 Piston large o-ring (012 BN70) | 6 Piston small o-ring (006 UR90) |
| 2 Piston | 7 Main seal (mounted in the seal retainer) |
| 3 Piston spring | 8 Seal retainer o-ring (010 BN70) |
| 4 Body | 9 Seal retainer (functions as an adjustment screw also) |
| 5 Body o-rings (3pcs, 012 BN70) | |

The only user-serviceable part in the LPR is the seal retainer. This seal needs to be changed in the unlikely case the LPR is creeping up.

CHANGING THE SEAL RETAINER

- 1 Screw out LPR back cover behind the marker using a 1/4" Allen wrench.
- 2 Screw out LPR seal assembly (brass) using a 3/16" Allen wrench.
- 3 Screw in new LPR seal assembly.
- 4 Screw LPR back cover in place securely.

If the user needs to replace the whole LPR assembly, follow these instructions:

- 1 Take frame off the marker.
- 2 Screw out LPR set screw using a 5/64" Allen wrench.
- 3 Screw out LPR cap using a 1/4" Allen wrench.
- 4 Pull out the LPR by screwing a rod with a 10/32 thread into the seal retainer (brass piece) inside the LPR and pulling it out.
- 5 Put everything back in reverse order. Be sure to grease the #019 o-rings, so as to prevent cutting them upon installation.
- 6 Tighten LPR back cover securely.

The LPR pressure can be set quite accurately even without an LPR test tool. Screwing the adjustment screw (seal retainer) all the way in will set the LPR pressure to approximately 25 psi. Now turning out the adjusting screw 180 degrees will increase the pressure by approximately 5 psi. For example, turning the screw 5 complete turns out will set the pressure to approximately 75 psi. Use a 3/16" Allen wrench to make all adjustments to the LPR. Turning the adjustment screw clockwise, or in, will lower the LPR's output pressure. Turning the adjustment screw counterclockwise, or out, will raise the LPR's output pressure.

! WARNING

When servicing your marker:

- **Make sure your hopper is removed from the DM6.**
- **Make sure there are no paintballs in the breech of the DM6.**
- **Always remove the air supply and relieve all gas pressure in the DM6 before disassembly.**
- **It is not recommended for the user to remove the LPR from the body and disassemble it.**



ON/OFF: USAGE AND CHANGING O-RINGS

The On/Off knob is located under the barrel in the front of the DM6 (see figure 2). Using the on/off is simple. To turn the gas off, turn the knob so that it is facing sideways. If you had gas inside the marker, it will bleed out. To turn the gas on, turn the knob so that it faces vertically.

The ON/OFF has three o-rings

- | | |
|------------|------------|
| 1 009 UR90 | 2 009 BN70 |
|------------|------------|

In case of a leak from the on/off, it is easy to service:

- 1 Take the frame off the marker.
- 2 Unscrew set screw holding on/off in place (screw just in front of the front frame screw).
- 3 Pull out on/off, change damaged o-ring(s).
- 4 Lube with grease.
- 5 Push back in.
- 6 Screw in set screw.
- 7 Put frame back on.
- 8 Gas up and test.

MAINTENANCE

The on/off needs very little maintenance. To help prevent o-ring failure and leaks, grease the on/off every four months or sooner, depending on the severity of playing conditions. Cold, wet weather will shorten the effective life of the grease. Heavy dust or fine sand can infiltrate the on/off and prevent it from moving smoothly and/or cut the o-rings.

NOTE: Air may still be present in the LPR and solenoid after the air has been vented from the marker by the on/off. Be sure all air has been vented by discharging the marker in a safe direction. If servicing the marker, removal of the bolt will also allow any trapped air to escape.



FIGURE 2

! WARNING

When servicing your marker:

- **Make sure your hopper is removed from the DM6.**
- **Make sure there are no paintballs in the breech of the DM6.**
- **Always remove the air supply and relieve all gas pressure in the DM6 before disassembly.**
- **It is not recommended for the user to remove the LPR from the body and disassemble it.**

HYPER2™ REGULATOR - ADJUSTMENTS AND MAINTENANCE



FIGURE 1



USAGE

Carefully connect your air hose from your bottle or air system to the Hyper2™ In-Line. The Hyper2™ In-Line is set by the factory to approximately 145psi. This pressure should give you a velocity of approximately 285fps.

ADJUSTMENTS

The output pressure of the Hyper2™ In-Line is adjusted by turning the brass seat housing. The seat housing screw is located up inside the bottom of the reg. A 3/16" Allen wrench will be needed for this operation. By turning the housing counterclockwise, you will increase the output pressure of the regulator to the marker. By turning the housing clockwise, you will decrease the output pressure of the regulator.

After each adjustment of the output pressure of the Hyper2™ In-Line, you will need to cycle your marker a few times. This will allow your marker and air system to stabilize at their new operating pressure. The Hyper2™ will need a break-in period of about 2,500 shots to let its seat form to the piston and reach its optimum performance.

The Hyper2™ has eight components and six o-rings

1 Retaining cap	6 Piston small o-ring (007 UR90)	11 Piston large o-ring (018 BN70)
2 Swivel	7 Swivel o-rings (013 BN70)	12 Reg cap o-ring (020 BN70)
3 Seat housing	8 Reg body	13 Reg cap
4 Retainer o-ring (010 BN70)	9 Shim stack	14 ASA o-ring (015 BN70)
5 Reg seat	10 Piston	

Shim Stack



Figure 2

Disassembly of the Hyper2™ In-Line is easily done with 3/8" and 5/16" Allen wrenches.

MAINTENANCE

To ensure top performance from the Hyper2™, maintenance should be performed every six months or sooner, depending on the severity of playing conditions. Cold, wet weather will shorten the effective life of the grease. Heavy dust or fine sand can infiltrate the Hyper2™ and prevent the piston from moving smoothly and/or cut the o-rings.

- 1 Make sure the inlet and outlet ports and connecting fittings are free of all dirt and paint.
- 2 Examine all o-rings for nicks or cuts.
- 3 Carefully inspect the seat for excessive wear that might cause spiking and over-pressurizing.
- 4 Clean any accumulated dirt out of the air chambers and passages.
- 5 Keep the piston o-rings and spring pack generously greased to allow smooth velocity adjustment and prevent erratic velocity spikes and drop off.
- 6 Clean off all old grease that may be contaminated with dirt; reapply fresh grease to the piston and other necessary areas.
- 7 Be sure to reassemble the internal components and shim stack (see figure 2) in the proper order and direction.
- 8 See diagram for assistance.

WARNING

- The Hyper2™ can hold a small residual charge of gas, typically 2 shots. Always discharge the marker in a safe direction to relieve this residual gas pressure.
- Always remove the regulator from the DM6 before servicing.
- Improper stacking of shims will cause failure of the regulator and possible damage to the DM6.
- Excessive dirt and debris can affect the Hyper2's™ performance and increase the need for servicing.

ANTI CHOP EYES - MAINTENANCE AND CHANGING

ANTI CHOP EYES

The Anti Chop Eye (ACE) system will prevent the DM6 from chopping paint by not allowing the marker to fire until a ball is fully seated in front of the bolt. The eyes use a beam across the breech. On one side there is a transmitter, and on the opposite side a receiver. In order for the marker to fire with the eyes turned on, the signal between the two eyes must be broken. After every shot, before the next ball drops in the breech, the eye transmitter and receiver must see each other. If there is a malfunction the LED's on the board will start blinking green. This means that the receiver and the emitter do not see each other. If this is the case, there are normally two reasons, either there is dirt, paint or grease blocking the beam, or the battery is so low there is not enough power to create a strong enough beam.

NOTE: If the battery is low, the marker may act as if the eyes are dirty or not fire at all. In this case, replace the battery.



FIGURE 2

SELF CLEANING EYE FEATURE

The DM6 is equipped with a self cleaning eye feature. There are two clear acrylic pieces mounted inside the breach of the gun covering the eyes (see figure 3). When the bolt tip O-ring passes these acrylic pieces, it sweeps off any dirt, grease or paint that could be blocking the eyes. Normally it is enough to just fire the DM6 to clean anything blocking the eyes. If this does not clean up the blockage, use a swab to clean up the breach. For a more through clean up, remove the eye plates. To remove the eye covers, you will need a 1/16" Allen wrench. Simply insert the allen wrench into the hole in the eye cover to access the retaining screw (see figure 2). As you back the screw out, the plate will be pushed up. Next, pull out the actual eye receiver/emitter from the self cleaning eye piece (avoid pulling the wires) and finally pull out the self cleaning eye piece with a pair of needle nose pliers (see figure 3). Avoid scratching the surface of the eye piece that sits inside the breach.




FIGURE 3

Take care not to lose the ball detent spring while removing the eye plate.

NOTE: Regular eye cleaning is recommended even if no paint is broken. Clean the eyes every two months or 10,000 shots to eliminate any built up dirt. Excess grease from the front bolt o-ring can build up in front of the eyes. Remember to check for this after greasing the bolt and cycling the marker a few times.




FIGURE 4

CHANGING BALL DETENTS

The ball detent system is also located under the eye covers. The ball detent system needs little or no maintenance. There is a spring behind each detent, which holds the detent forward. This spring pressure should be easily overcome with very little force, such as a paintball moving past. If you are experiencing double feeding or chopping, check the condition of your ball detents with your finger to make sure they are not stuck in the up or down position and that they move in and out of the breech freely. If excessive broken paint or dirt has jammed your ball detents, remove the eye plates (being careful not to lose the detent springs) and pull the detents out for a thorough cleaning (see figure 4). Reinstall the detents, springs and eye covers after you have sufficiently cleaned the detents and breech.

NOTE: TAKE CARE WHEN REPLACING THE EYE COVERS. OVER-TIGHTENING THE RETAINING SCREW COULD RESULT IN STRIPPING THE THREADS.

ULTRALITE FRAME

FIGURE 1



ADJUSTING YOUR TRIGGER

The trigger's forward travel, over travel and spring tension are fully adjustable so that the user can fine-tune the trigger to his or her exact liking. You do not need to remove the frame from the gun in order to adjust the trigger pull.

- There are two adjustment screws located on the right side of the Ultralite frame (see figure 1) and one adjustment screw behind the trigger. The two screws on the side of the frame adjust the travel of the trigger. The one located behind the trigger is used to change the tension of the trigger spring.

TO ADJUST TRIGGER TRAVEL

- Use a 5/64" Allen wrench to make the desired adjustments.
- The screw toward the front of the trigger (#1 in figure 1) controls the forward travel. Screwing it in will shorten the trigger's length of pull.
 - Note: If this screw is adjusted too far, the switch will be held down at all times and the marker will not fire.**
- The screw toward the rear of the trigger (#2 in figure 1) controls the over travel. By turning this screw you can adjust how far the trigger will travel after it reaches the firing point.
 - Note: If this screw is adjusted too far, the trigger will not be allowed to travel far enough to depress the switch and fire the marker.**

TO ADJUST SPRING TENSION

- Use a 5/64" Allen wrench to make the desired adjustment. The adjustment is made by pushing the allen key through a hole in the trigger.
- To make the trigger pull stiffer, turn the allen key clockwise or in.
- To make the trigger pull lighter, turn the allen key counterclockwise or out.

INTEGRATED LOCKING DOVETAIL FEATURE

The UltraLite frame comes equipped with an integrated locking dovetail. There is a locking screw located on the bottom right side of the UltraLite frame. It can be accessed with a 1/8" allen key through a hole in the grips panels. To unlock a part attached to the dovetail of the frame, turn the locking screw counter clockwise one full turn and slide part off the rail. To attach a part to the rail, slide the part on and turn the locking screw clockwise until part is firmly locked in place.

REMOVING ULTRALITE FRAME FROM THE DM6

- If there is ever need to remove the Ultralite frame from the DM6 make sure to follow these steps.
- Remove three grip panel screws with a 3/32" allen wrench from the right side of UltraLite frame
 - Disconnect the solenoid wire and the eye wire from their sockets by gently pulling them out
 - Using a 3/32" allen key, turn the front frame screw counterclockwise one full turn
 - Finally, turn out the back frame screw and slide the frame back and down until it comes off the DM6

To connect the frame follow above steps in reverse order.

NOTE: BE SURE THAT THE FRAME AND TRIGGER ASSEMBLY ARE KEPT CLEAN. IF THERE IS EXCESS DIRT OR PAINT BUILD UP AROUND THE TRIGGER, THE TRIGGER WILL NO LONGER MOVE FREELY. IN ADDITION, PAINT AND DIRT CAN CAUSE THE MICROSWITCH TO NOT FUNCTION PROPERLY OR FAIL. BE SURE YOU DO NOT PINCH THE WIRES BETWEEN THE FRAME AND THE BODY WHEN REATTACHING THE FRAME AND BODY.



PARTS LIST

- Adjustable Feed Neck
- On/Off Knob
- Ball Detent
- Eye Cover
- Self Cleaning Eye Lens
- Hyper²
- On/Off Retaining Screw
- "ACE" Eye
- Solenoid
- Front Frame Screw
- Ultralite 45 Frame
- Rear Frame Screw
- LPR Retaining Screw
- LPR
- LPR Cap
- Fuse Bolt
- DM6 Body

WARNING

- Be sure the trigger is not adjusted to the point where it is too sensitive and may cause accidental discharge of the marker.
- Removing the trigger spring will cause premature wear on the microswitch, resulting in failure.
- Be sure you do not pinch the wires between the frame and body if reattaching the frame to the body.

TROUBLE SHOOTING GUIDE

DM6 TROUBLE SHOOTING

AIR LEAK BETWEEN THE FRAME AND BODY

- First remove the frame and try to pinpoint the source of the leak:
- If it comes from the small hole under the LPR, you need to remove your LPR. The cause of the leak is either one of the #015 o-rings on the outside of the LPR or the #006 o-ring found inside the LPR (see page 10).
- If it comes from somewhere around the solenoid, the first thing to do is to turn the on/off knob to the off position. If the leak continues, the cause is a bad o-ring on the on/off. If it stops there are three likely causes:
 1. #015 on the bolt seal
 2. #020 on the cylinder (the one on the middle of the cylinder)
 3. Seat under the solenoid

AIR LEAK FROM THE BACK OF THE LPR PLUG

- Remove the LPR and change the back-most #015 o-ring on the LPR body. If that does not help, change the seal retainer inside the LPR body. Refer to page 10 of the manual for disassembly instructions.

INCONSISTENT VELOCITY OVER THE CHRONO

- In-line regulator not giving consistent pressure: refer to the Hyper2 manual for service, or if using an after-market regulator, refer to its manufacturer.
- Low battery: change the battery.
- Bad seals in the bolt: take out the bolt, clean it, lube it with Dye Slick Lube™. Replace any o-rings that seem damaged, swollen or in otherwise bad shape. Most likely the o-ring at fault is the #017 front wall o-ring. Also check that the #014 o-ring on the bolt tip is in place.
- LPR pressure set incorrectly or LPR pressure fluctuating: if pressure is too low, the bolt will not cycle correctly. Try turning the LPR pressure a bit higher. If the pressure seems inconsistent, you can have an authorized DM6 center check the LPR pressure. List of tech centers can be found at www.dyematrix.com.
- Dwell set too low: if you set the dwell too low, the dump chamber will not empty completely and will cause erratic velocities. Refer to board settings page for information on setting the dwell.

TRIGGER BOUNCE

- If you are having excessive trigger bounce when firing the gun, make sure you have an uncut spring behind the trigger. Adjust the trigger so that the firing point of the trigger pull is located about halfway through the travel of the pull. Raise the trigger sensitivity value.

AIR LEAK BETWEEN THE BODY AND REAR CAP

- Replace the #020 o-ring on the bolt rear cap.

MARKER WILL NOT FIRE

- A low battery may cause malfunctions to the marker. In this case, the battery should be changed as soon as possible.
- Check to make sure the on/off is in the on position.
- If the LED light is red, the marker will not fire because there is no ball in the breech. Hold the trigger for 1 second and the marker should fire. If it does not fire after holding the trigger, or if the LED light is green and it will not fire:
 - Make sure dwell setting is at stock value.
 - Make sure the trigger is adjusted properly and is actuating the microswitch.
 - Make sure there are no broken solenoid wires.
 - Sticking bolt: pull out bolt and re-grease o-rings.

MARKER SHOOTING SLOW WHEN EYE IS ON AND BLINKING GREEN

- The eyes are not working correctly. Clean the eyes. You'll know that they are clean if the LED turns red when there is nothing inside the breach of the DM6.
- Make sure the eye wires are not broken or pinched.
- The battery may be low. In this case, the battery should be changed as soon as possible.

MARKER ISN'T WORKING THOUGH EYES ARE CLEAN AND ALL WIRES ARE CONNECTED; MARKER DOES WORK IF EYES ARE TURNED OFF

- Change the battery. The voltage in the battery is too low for the eye to function correctly.

MARKER WILL NOT TURN ON OR OFF; CONTINUOUSLY CYCLES THROUGH BOOT-UP; EYES WILL NOT TURN ON OR OFF

- The button pad may need replacement.

AIR LEAK THROUGH THE BARREL

- There are three possible o-rings that cause this leak:
- If the leak comes through the inside of the bolt, replace the #013 on the bolt top hat. If the cause is this #013 o-ring, the input pressure to the gun is likely too high.
- If it's leaking from the outside of the bolt shaft, the bad o-ring is either the #017 on the inside of the bolt cylinder or the #020 on the outside of the bolt can.

AIR LEAK FROM THE BACK HOLE OF THE BOLT

- Take out the bolt, unscrew the back part of the bolt and change the #009 o-ring on the back of the bolt shaft.

HYPER2™ TROUBLE SHOOTING (REFER TO PAGE 12)

NOTE: TO TAKE APART THE REGULATOR, USE A 5/16" ALLEN WRENCH ON THE BOTTOM AND A 3/8" ALLEN WRENCH ON THE TOP. TWIST COUNTERCLOCKWISE TO OPEN. DO NOT USE ANY OTHER METHOD.

NO OR POOR AIR FLOW

- Check for blocked air passage in hose line or regulator.
- Adjustment screw may be screwed in too far.
- Seat may have excessively deep piston groove cut into it. Replace if needed.

ERRATIC VELOCITY OR SHOOT DOWN

- Piston or shim stack may be binding due to excessive dirt or lack of lubricant.
- Seat may be dirty or damaged. Clean and grease regulator. Inspect and replace damaged parts as needed.
- Make sure shim stack is stacked properly.

OUTPUT PRESSURE CREEPS UP

- Dirty seat or damaged piston face. Clean and inspect; if either is damaged, replace.
- Piston o-ring #007 UR90 may be damaged.

AIR LEAK FROM SIDE VENT HOLE

- Piston o-rings #007 UR90 and #018 BN70 may be damaged. Inspect o-rings. Replace if any visible nicks or cuts are found.

AIR LEAK FROM BOTTOM OF ADJUSTMENT SCREW

- This is a safety bleed-off to help prevent over-pressurizing. De-gas the Hyper2™; be sure all air is vented out of the regulator. Supply air back to the regulator. The leak should stop. If the leak persists, replace the regulator seat. Make sure there are no nicks or scratches on the raised ring at the bottom of the seat-retaining cavity.

WARRANTY

DYE Precision, Inc.

Warrants for one year to the initial retail purchaser, from the initial date of purchase, that the paintball marker and regulator are free from defects in materials and workmanship, subject to the requirements, disclaimers and limitations of this warranty. Disposable parts, normal maintenance and standard wear and tear parts such as batteries, o-rings and seals are not warrantied. The solenoid and electronic components on the marker are warrantied for six months. This warranty does not cover scratches, nicks, improper disassembly, improper re-assembly, misuse, neglect or improper storage. Modification to the product will void the warranty. The only authorized lubricant for the marker is Slick Lube™. Use of any other lubricant will void your warranty. This warranty is limited to repair or replacement of defective parts with the customer to pay shipping costs. Warranty card and proof of purchase must be submitted to Dye Precision for warranty to be in effect. This warranty is not transferable. This warranty does not cover performance. Paintball markers are non-refundable.

TECHNICAL SUPPORT

Our Technical Support Department is open Monday through Friday, from 9am to 5pm, PST, and can be reached at 858-536-5183. Additional support is available through our web site, www.dyepaintball.com.

DISCLAIMER

The specifications & photographs in this material are for information and general guidance purposes only.

Our products are continually updated and changes may be made to specification, design or appearance from time to time. These are subject to change without notice. Contents of box may therefore vary from owner's manual. For details of changes in design, specification or appearance consult your local distributor or dealer.

The FUSE™ bolt, Hyper2™ and Slick Lube™ are registered trademarks. Design rights, copyrights and all other rights reserved. All patterns, drawings, photographs, instructions or manuals remain the intellectual property of the manufacturer.

Covered by U.S. Patent 5,613,483. Additional patents pending. All rights will be strictly enforced.

DYE Precision, Inc.

USA 10637 Scripps Summit Ct. San Diego, CA 92131
P 858-536-5183 F 858-536-5191

EUROPE Unit 1, ZK Park, 23 Commerce Way
Croydon, Surrey CRO 4ZS United Kingdom
P +44 (0) 20-8649-6330 F +44 (0) 20-8649-6339

ASIA 3F-2, No. 287, Jung Jeng Rd., Luju Hsiang
Taoyuan 338, Taiwan (R.O.C.)
P +886-3-312-6540 F +886-3-311-8723