TIPPMANN

98 CUSTOM
BASIC PARTS LIST
(NON-A.C.T. INTERNALS)

98-39 Stock Barrel
98-40 Barrel O-Ring
SL2-4 Front Bolt O-Ring
TA01016 Linkage Arm
02-17 Front Bolt
98-12A Valve/Rear Bolt O-Ring (2)
98-21NR Custom Power Tube
02-22 Velocity Screw
98-V Valve Complete
TA02011 Rear Bolt
98-13 Bolt Handle
TA05107 Custom Receiver (Left)
98-01A Receiver Bolt (Short) (5)
98-01B Receiver Bolt (Long)(1)
TA02007 Name Plate
98-07R Front Grip (Right)
98-07L Front Grip (Left)
TA05005 Rear Bolt Plug
CA-14 Drive Spring
CA-15 Guide Pin
TA02019 End Cap
98-57 Buffer O-Ring
CA-02A Grip Screw (2)
TA05003 Split Grip (Left)

Front Sight
Front Sight Spring
Front Sight Pin

INTERNAL VALVE PARTS:
Valve Disassembly Not Recommended

98-25N Valve Body
SL2-25 Valve Seat O-Ring (2)
PA-31A Valve Snap Ring
98-56 Valve Plug
98-32 Valve Spring
98-PL Valve Plunger
CA-27 Front Valve Seat

TRIGGER ASSEMBLY

98-20 Trigger Spring (Yellow)
98-33 Pins (4)
CA-36 Sear Pin (Black)
TA02036 Sear Spring
02-35 Sear
98-18 Slider (yellow spring not visible)
98-36A Trigger
98-38 Trigger Guard

1) Place 4 dowel pins and 1 black sear pin into locations as shown.
2) Then place the trigger and sear onto pins as shown.
3) Insert sear spring as shown.
4) Insert trigger spring (yellow) as shown.

⚠ WARNING

DO NOT DISASSEMBLE THIS MARKER WHILE IT IS PRESSURIZED WITH AIR. DO NOT PRESSURIZE A PARTIALLY ASSEMBLED MARKER.

PL-42D Hopper Nut
98-43 Feed Elbow Latch
TA05052 Feed Latch Bolt (2)
98-14 Front Sight
98-15 Front Sight Pin
98-44 Front Sight Spring
98-45 Flat Washer
PL-42C Hopper Bolt
98-04 Feed Elbow
98-04A Feed Elbow Pin (2)
98-26 Valve Lock Bolt (2)
98-27P Sight Dove Tail
98-28P Rear Sight
9-PA Receiver Nut (6)
FA-18 Ball Latch
CA-02A Grip Screw (2)
98-33 Receiver Dowel Pin (4)
98-20 Trigger/ Return Slide Spring (2) (Yellow)
TA02036 Sear Spring
02-35 Sear
98-37N Safety
98-38 Trigger Guard
CA-36 Sear Pin (Black)
TA05004 Split Grip (Right)
98-36A Trigger
98-18 Trigger Return Slide
98-09C Gas Line
TA05108 Receiver (Right)
98-55 Safety O-Ring (Red)
FA-07 Safety O-Ring (Black)
98-19 Return Slide Dowel Pin (2)
CA-08B Adapter Nut (2)
PL-01A Adapter Bolt (short)
98-06A Adapter Bolt (long)
98-06 Tank Adapter

REV 08/22/2007