



- | | |
|-----------------------------|-------------------------------------|
| 0002 VALVE SPRING | 0036 COVER PLATE-BALL RETAINER |
| 0003 EXHAUST VALVE | 0037 SPLIT WASHER-SMALL |
| 0004 VALVE GUIDE | 0038 RETAINER SCREW-COVER PLATE |
| 0005 O RING-VALVE GUIDE | 0039 BARREL |
| 0006 O RING-VALVE GUIDE | 0040 TRIGGER SPRING |
| 0007 RETAINER SCREW | 0046 DOUBLE TRIGGER |
| 0008 SPLIT WASHER | 0047 DOUBLE TRIGGER SHOE |
| 0010 SAFETY CATCH | 0049 GRUB SCREW-TRIGGER SHOE |
| 0011 SAFETY BALL | 0099 45 GRIP FRAME SCREW |
| 0012 SAFETY SPRING | 0100 45 GRIP ADAPTOR |
| 0013 FRAME SCREW-FRONT | 0155 DOUBLE TRIGGER FRAME - 45 GRIP |
| 0014 DOWEL PIN 1/8 | 0160 45 GRIP - LEFT HAND |
| 0015 FRAME SCREW-REAR | 0161 45 GRIP - RIGHT HAND |
| 0016 SEAR | 0200 SCREW - 45 GRIP |
| 0017 GRIP | 0220 DUMPY BOTTOM LINE |
| 0018 BOTTOM LINE | 0225 DUMPY BOTTOM LINE SCREW |
| 0019 HOSE HI-PRESSURE | 1301 FORE GRIP |
| 0020 ELBOW | 1305 VALVE BODY |
| 0021 GRIP RETAINING SCREW | 1320 FORE GRIP SCREW |
| 0022 O RING-HAMMER | 1330 O-RING FEED BOWL |
| 0023 HAMMER | 1500 BODY |
| 0024 BUMPER | 1510 COCKING PIN |
| 0025 SEAR SPRING | 1515 DELRIN BOLT |
| 0026 MAIN SPRING | 1525 VELOCITY ADJ.BODY |
| 0030 O RING-VEL ADJ. INSERT | 1535 VELOCITY ADJ.INSERT |
| 0032 BOLT PLUNGER | |
| 0035 BALL RETAINER | |

MK3