


BT™
BT Delta Elite™



description	item no.	description	item no.
1 Tank Adapter	17044	24 Rear Bolt & External Valve O-ring	19426
2 Expansion Chamber Plug	17045	25 Shock Absorber O-ring	19427
3 Delta Elite Name Plate	17055	26 Gas Line	19435
4 Power Tube	19384	27 Long Tank Adapter Bolt	19439
5 Ball Detent	19386	28 Short Tank Adapter Bolt	19440
6 Cup Seal	19387	29 Valve Snap Ring	19442
7 Left Upper Receiver	19388	30 Internal Valve Spring	19444
8 Bolt Plug	19389	31 Bolt Handle Rubber Cover	19445
9 Barrel Adapter	19391	32 Drive Spring	19447
10 Valve Body	19392	33 Drive Spring Guide	19448
11 Internal Valve Seat	19393	34 Barrel Adapter O-ring	19452
12 Plunger Cup	19394	35 Bolt Handle	19454
13 Rear Valve Seat	19395	36 Rear Bolt	19455
14 Right Upper Receiver	19406	37 Delta Elite Apex Barrel Assembly	20166
15 Front Bolt	19409	38 Front Sight Rail	20169
16 Linkage Arm	19410	39 Magazine Retention Screws	20170
17 Long Receiver Bolt	19413	40 Magazine Holder Nut	20172
18 Short Receiver Bolt	19414	41 Magazine Assembly	20191
19 Receiver Nuts	19415	42 Magazine Locking Arm	20194
20 Valve Screw	19416	43 Stock Assembly (Complete)	20195
21 Velocity Screw	19418	44 Rear Sight Rail Assembly (Complete)	20196
22 Front Bolt O-ring	19424	45 Valve Stem	99126
23 Internal Valve O-ring	19425	Complete Valve (Not shown)	19382