


Pure Energy® Reactor



description	item no.	description	item no.
1a. Gas Distribution Body 3K	41310	12a. H.P. 5000 PSI Unified Burst Disk	47046
1b. Gas Distribution Body 4.5K	41311	12b. H.P. 7500 PSI Unified Burst Disc	47029
1c. Gas Distribution Body 5K	41312	13a. H.P. Gauge 4K	46091
2. Belleville Spring Pack	41313	13b. H.P. Gauge 5K	46092
3. Regulator Seat	41314	14. 004-90 Urethane O-Ring	10256
4. Piston	41315	17. L.P. 1800 PSI Unified Burst Disk	41025
5. Pin Valve Spring	41316	18. 10-32 Bonnet Lock Screws	41318
6. Pin Valve	41102	19. Piston Assembly	41315
7. 006 Teflon O-Ring	40925	20. Fill Nipple Assembly	41049
8. Bonnet (includes jewel & set screws)	41101	21. Restrictor (Not Pictured)	41319
9. 015-90 Bottle O-Ring	41010	Rebuild Kit	40611
10. 012-90 Urethane O-Ring	40919	LP Drop In Kit	40605
11. 008-90 Urethane O-Ring	40923		

