


PARTS DIAGRAM



Part List

PART NO.	DESCRIPTION	QTY
MKP-1-R	MKP Main Body Right	1
MKP-1-L	MKP Main Body Left	1
MKP-5	Magazine Feed Cover	1
MKP-6	Hook	1
MKP-7	Bottom Cover	1
MKP-8	Magazine Housing	1
MKP-9	Magazine Set Screw	1
MKP-10	Magazine Set Nut	1
MKP-13	Nut-1	3
MKP-14	Air Plug	1
MKP-15	Air Plug O-Ring	1
MKP-16	Nut-2	1
MKP-26	Magazine Hook	1
MKP-27	Magazine Release	1
MKP-42	Magazine Spring	1
MKP-43	Magazine Housing Pin	1

Installation Information:

1. Verify that all the parts and the designated quantities are supplied in accordance to the part list table
2. Use your manufacture user manual as reference to disassemble and reassemble of the new parts provided
3. Additional installation guide and step by step installation videos are available at tacamopaintball.com/support/