Spyder Flash w/ LCD



NEW ITEM #	NAME OF PARTS
01	Barrel Plug
02J	Barrel Insert
03A	Ball Bearing
03B	Spring
03C	Ball Bearing Cap
04G	Detent Cover
05A	M4 X 6 Screw (black)
05B	M4 X 6 Screw (silver)
05C	M4 X 8 Screw w/ washer
07	M4 X 14 Screw w/ washer
09	O-ring #015 80D
09B	Bolt O-ring
10A	Valve Spring
11	Cup Seal Guide
13	Valve Pin
12A	Cup Seal (brass)
14	Valve Body
15	Valve Body Screw
16	M5 X 12 Screw w/ washer
20	Barrel O-ring
21	Bolt Pin
22	Bolt Screw
25	Striker Spring
27	Strilker Spring Guide
37K	Disconnect Hose
1406	Flash Receiver (green/black)
1408	Verical Adapter (green/black)
1444	Mini Fore Grip (Green/black)
1402E	Flash 12" Barrel (green/black)
1404G	Direct Feed (green/black)
1408L	Low Pressure Chamber (green/black)
1417H	Venturi Cocking Bolt (green/black)
1428C	Striker Plug (green/black)
35LL	Drop Forward (blue)
35LK	Drop Forward (black)
1444H	Model S Expansion Chamber (green/black)
1447G	Beaver Tail (greeb/black)
1506	Flash Receiver (purle/black)
1508	Vertical Adapter (purple/blue)
1544	Mini Fore Grip (purple/blue)
1502E	Flash 12" Barrel (purple/blue)
1504G	Direct Feed (purple/blue)
1508L	Low Pressure Chamber (purple/blue)
1517H	Venturi Cocking Bolt (purple)
1528C	Striker Plug (purple/blue)
1544H	Model S Expansion Chamber (purple/blue)
1547G	Beaver Tail (purple/blue)
22B	M4 x 8 Screw w/ washer

23B	Quick Disconnect Pin
19A	Strilker O-ring
23C	Disconnect Lock Pin
26A	Striker Buffer
27A	Flat Disc
29B	Lock Screw
29C	Thumb Adjuster w/ Lock Screw
33F	Nut Screw
36D	5/32" x 5/8" Screw w/ washer
36E	5/32" x 7/8" Screw w/ washer
37A	Fitter O-ring #009
37B	Air Filter
37C	#011 O-ring
37D	Plastic Washer
39B	Cocking Rod (silver)
39C	Cocking Rod (black)
41H	Spyder Flash Spare Parts Kit
42F	M8 x M8 Adapter
JE1002	Flash/LCD Trigger Frame (silver)
48	Trigger Roll Pin
49B	Sear Roll Pin
49C	Touch Switch Roll Pin
E33	ON/OFF Screw (M2 x 6)
E33A	ON/OFF Switch
JE18C	Coil Set
JE12	Sear
JE15	Copper Screw
JE18A	Striker Bolt
JE18B	Coil Set Screw (1/8")
JE26	Charge Pin
JE27	Touch Switch
JE29	Circuit Board Screw
JE31C	Trigger
JE31E	Sear Spring
JE31F	Trigger Spring
JE31D	Trigger Adjust Screw
JE32A	ESP Grip Cover
JE33C	Grip Cover Screw
JE1015	Rechargeable Battery 9.6v
1635C	C/A Adapter w/ Regulator (blue)
1735C	C/A Adapter w/ Regulator (black)
35D	Gauge
35E	Regulator Adjust Screw
35F	M 4 X 5 Screw
1631A	F1 (Select Switch)
1631B	F2 (Set Switch)
1631C	F3 (Lock Switch)
1629	Circut Board w/LCD Panel